

USER MANUAL

High Power UVC Ultraviolet Disinfection Lamp (150W / 300W)

WARNING

Please read the User Manual before operating the UV Lamp

1. Don't look directly at the ultraviolet light source.
2. Long-term exposure to ultraviolet rays will cause irritation on people's skin and eyes. To achieve the disinfection result in the area, doors and windows must be closed, people and animals must leave.
3. Although our 254nm UVC light doesn't not emit any ozone during the disinfection process, proper air ventilation is still recommended.

Product Introduction:

The UV disinfection lamp is suitable for sterilizing and disinfecting up to 150W up to 1079 sq² / 300W up to 2150 sq² ft space. It damages the DNA of microorganisms and makes it lose the function of reproduction and self-replication.

Ultraviolet disinfection lamps can disinfect bacterial propagules, spores, mycobacteria, corona viruses, fungi, rickettsia and chlamydia, etc. These lamps can be used in the offices, schools, clinics and living area for disinfection. According to scientific data and test results of UVC lamps, disinfection rate can be reached up to 99.9%.

150W UV-C Disinfection Area Approx	439 Sq Ft	778 Sq Ft	1076 Sq Ft
Recommended Sterilization Duration	15 Minutes	30 Minutes	60 Minutes
300W UV-C Disinfection Area Approx	621 Sq Ft	1241 Sq Ft	2150 Sq Ft
Recommended Sterilization Duration	15 Minutes	30 Minutes	60 Minutes

Product Specifications:

Product Name: High Power UVC Ultraviolet Disinfection Lamp

Rated Power: 150W / 300W

Rated Voltage: 110V / 220V

Time Mode: Time Panel control and Wireless Remote Control

Tube Material: Quartz Ultraviolet Lamp

Application Area: 150W up to 1079 sq² / 300W up to 2150 sq²

Warranty: 3 Years Limited



Operation Procedure:

1. Plug the power plug into a power outlet.
2. Turn the timer dialer counter clockwise to a desired disinfection time, the lamp will automatically turn on after 15 seconds. People and animals must leave the area during the 15 seconds delayed clock. You can also use the remote control to turn the lights on and off.
3. The user can also use the remote control to turn on or off the lamp. However, the timer dialer must be turned all the way to initiate the lamp. If the user chooses the timer mode, please select the desired disinfection time on the remote control by pressing the timer on "15 minutes", "30 minutes" or "60 minutes". The lamp will automatically turn on 15 seconds after a designated time was chosen.
4. The UV lamp will automatically turn off and return to the shutdown state after the chosen time expires. If the user doesn't choose the disinfection time with remote control, the lamp will automatically turn off after 60 minutes.